



Open Environmental Restoration Resource (OER2) Webinar

Advances in Microbial Characterization for MNA & Bioremediation

Presented by: Dr. Anthony Danko
NAVFAC Environmental Restoration Program

November 15 2017

- **Submit all questions via chat box throughout the presentation**
- **Presentation is being recorded**
- **Complete the webinar survey (main feedback mechanism)**

Disclaimer:

This seminar is intended to be informational and does not indicate endorsement of a particular product(s) or technology by the Department of Defense or NAVFAC EXWC, nor should the presentation be construed as reflecting the official policy or position of any of those Agencies. Mention of specific product names, vendors or source of information, trademarks, or manufacturers is for informational purposes only and does not constitute an endorsement or recommendation by the Department of Defense or NAVFAC EXWC. Although every attempt is made to provide reliable and accurate information, there is no warranty or representation as to the accuracy, adequacy, efficiency, or applicability of any product or technology discussed or mentioned during the seminar, including the suitability of any product or technology for a particular purpose. Participation is voluntary and cannot be misconstrued as a new scope or growth of an existing scope under any contracts or task orders under NAVFAC

Dr. Anthony Danko

(Presenter)

- **Environmental Engineer (NAVFAC EXWC)**
- **65 Professional Publications**
- **Specializes in**
 - **Portfolio optimization**
 - **Innovative technology development**
 - **Bio-remediation**
- **B.S. in Chemical Engineering (Rensselaer Poly Tech)**
- **M.S. in Civil and Environmental Engineering (U. of Pittsburgh)**
- **Ph.D. in Environmental Engineering and Science (Clemson University)**



anthony.danko@navy.mil

OER2 Webinar Series



•Why Attend?

- Obtain and hear about the latest DOD and DON's policies/guidance, tools, technologies and practices to improve the ERP's efficiency
- Promote innovation and share lessons learned
- FEEDBACK** to the ERP Leadership

•Who Should Attend?

- ERP Community Members: RPMs, RTMs, Contractors, and other remediation practitioners who support and execute the ERP
- Voluntary participation

•Schedule and Registration:

- Every other month, 4th Wed (can be rescheduled due to holidays)
- Registration link for each topic (announced via ER T2 email)

•Topics and Presenters:

- ERP community members** to submit topics (non-marketing and DON ERP-relevant) to POCs (Gunarti Coghlan – gunarti.coghlan@navy.mil or Tara Meyers – tara.meyers@navy.mil)
- Selected topic will be assigned Champion to work with presenter



Advances in Microbial Characterization for MNA & Bioremediation

Dr. Anthony Danko
NAVFAC EXWC



- **Placeholder slide for survey**
- **How familiar are you with Molecular Biological Tools?**
 - **Very familiar**
 - **Somewhat familiar**
 - **Not familiar**

• Why are we interested in microbiology?

– Provide insights into bioprocesses occurring in the subsurface

- Biogeochemical
- Biodegradation
- etc.

What is going on in the subsurface?

Are microorganisms present?



How many different types?

Are microorganisms active?


What tools can be used?


- **Traditional microbial methods may not be able to provide you the information that is needed to assist in site assessment and remediation**
 - **Culturable versus non-culturable microorganisms**


- **Molecular biology** studies gene structure and function at the molecular level

- **Field overlaps with other areas such as:**
 - **Biochemistry: Structures, functions, and interactions of macromolecules**

 - **Genetics: Genes**







- **Techniques Available**

- **qPCR**

- What are the concentrations of specific microorganisms or genes of interest?

- **Next Generation Sequencing (NGS)**

- Which microorganisms are present?

- **Stable Isotope Probing (SIP) and Compound Specific Isotope Analysis (CSIA)**

- Is degradation occurring?

- **Others**

- **Techniques Available**

- **qPCR**

- **Next Generation Sequencing (NGS)**

- **Stable Isotope Probing (SIP) and Compound Specific Isotope Analysis (CSIA)**

- **Others**



Survey

- Placeholder slide for survey
- Have you used qPCR as part of your Environmental Management Strategy?

- **Determines the concentration of a specific microorganism or particular functional gene of interest**

- **How much Dehalococcoides is present?**


- 10^4 cells/mL is generally required for effective bioremediation

- **How much TOD (toluene/benzene dioxygenase) is present?**

- **Technique requires knowledge beforehand of the microorganisms and/or genes of interest and specifically targets them!**


- **Established link between function of gene or microorganism to the process**

Genes




Microorganisms


Genes




PCE




TCE



***cis*-1,2-DCE**



VC



Ethene



Etheneotrophs
VC-assimilators

EtnC = Alkene Monooxygenase
EtnE = Epoxyalkane CoM Transferase

What genes are we interested in? – Aerobic Processes



Genes



EtnC = Alkene Monooxygenase
EtnE = Epoxyalkane CoM Transferase



METABOLISM




Monooxygenases 'Non-specific'

COMETABOLISM



Can be partial or complete

TCE
cDCE
VC




TCE-epoxide
cDCE-epoxide
VC-epoxide

What genes are we interested in? – Aerobic Cometabolic Processes




Genes



TOD = Toluene Dioxygenase
sMMO/pMMO = soluble/particulate Methane Monooxygenase
PHE = Phenol Hydroxylase
RMO = Toluene Monooxygenase
RDEG 2 = Toluene Monooxygenase
EtnC = Alkene Monooxygenase


Microorganisms

What genes are we interested in? – Monoaromatic Hydrocarbons



Toluene

**Benzene/toluene
dioxygenase (TOD)**



cis-cyclohexa-3,5-diene-1,2-diol


TOD = Toluene Dioxygenase
 RMO = Toluene Monooxygenase
 RDEG = Toluene Monooxygenase
 PHE = Phenol Hydroxylase
 TOL = Xylene/Toluene Monooxygenase
 EDO = Ethylbenzene/Isopropylbenzene Dioxygenase
 BPH4 = Biphenyl/Isopropylbenzene Dioxygenase

BCR = Benzoyl Coenzyme A Reductase
 BSS = Benzylsuccinate Synthase
 ABC = Benzene Carboxylase

Aerobic

Anaerobic

What genes are we interested in? – Polyaromatic Hydrocarbons




NAH = Naphthalene Dioxygenase
 PHN = Phenanthrene Dioxygenase

BCR = Benzoyl Coenzyme A Reductase
 NMS = Naphthylmethylsuccinate Synthase
 ANC = Alkylsuccinate Synthase

} Aerobic
 } Anaerobic

What genes are we interested in? – Alkanes



ALKB = Alkane hydroxylase

ASSA = Alkylsuccinate Synthase



Aerobic

Anaerobic

- **Techniques Available**

- **qPCR**

- **Next Generation Sequencing (NGS)**

- **Stable Isotope Probing (SIP) and Compound Specific Isotope Analysis (CSIA)**

- **Others**



Survey

- Placeholder slide for survey
- Have you used NGS as part of your Environmental Management Strategy?

- **Information about the entire community**
 - Not targeting a specific functional gene or microorganism as in qPCR
 - No prior knowledge of the genes or microorganisms are needed
- **Not quantitative but relative amount**
- **Information on community shifts over time**
- **Function?**
- **May not detect low concentrations of microorganisms**

- **Techniques Available**

- **qPCR**

- **Next Generation Sequencing (NGS)**

- **Stable Isotope Probing (SIP) and Compound Specific Isotope Analysis (CSIA)**

- **Others**



Survey

- Placeholder slide for survey
- Have you used SIP or CSIA as part of your Environmental Management Strategy?



•Variety of isotopes in the environment that can be used


- Naturally occurring isotopes (% varies)
- Same protons, more neutrons
- Stable
- Tracking the isotope

$^{13}\text{C}/^{12}\text{C}$

$^{15}\text{N}/^{14}\text{N}$

S, H, Cl, etc

$$\delta^{13}\text{C} = \frac{R_x - R_{\text{std}}}{R_{\text{std}}} \times 1000$$



Both SIP and CSIA look for enrichment in the $\delta^{13}\text{C}$ values!


Units are per mil, ‰ (if $\delta^{13}\text{C} = +10$, that means 10 per thousand)



Is degradation occurring?

- Looking for enrichment (like SIP)
- Not added (unlike SIP), naturally present
- Can be used for electron donors or acceptors (unlike SIP)
- ^{12}C bonds are slightly weaker and easier to break
- ^{13}C bonds are slightly stronger and harder to break


$$k_{12} > k_{13}$$




^{13}C and ^{12}C are decreasing with time
Increasing ratio of ^{13}C

OU3, NAS Jacksonville


- Occupies 134 acres on eastern side of installation
 - Industrial/commercial land use
- Fleet Readiness Command (FRC) (formerly NADEP) primary tenant on installation since 1940s
- Former dry cleaner facility located within OU3 property
- 7 identified groundwater plumes (Areas A – G)
- Buildings 780 and 106 also sources of contamination



OU3 Cross-Section - Northern Plume



Pilot Test Summary







- 50 DPT injection locations
- December 2013
- 2 injection intervals per location
- 145,000 gallons of an 0.7% emulsified vegetable oil solution (EDS-ER™)
- Average flow rate of 1.8 gpm
- 100 liters of KB-1® and KB-1® Plus injected
- Bromide tracer used
- 10 performance monitoring wells
- 4 soil gas probes


Legend

- Temporary DPT Injection Locations
- Existing Sand Wells
- Target Treatment Area (TTA)
- ⊕ Existing Soil Gas Probes
- Existing Sand/Clay Wells


Source: Geosyntec 2016



Upgradient Well MW-40S



Pilot Test Well PZ-02



% of Bacteria

Dehalococcoides 0.01%

Dehalogenimonas 0.2%

Methylobacter 9%

Sulfuricurvum 7%

% of Bacteria

Dehalococcoides 5%

Geobacter 24%

Methylobacter 9%


Desulfuromonadales 27%

Aerobic and Anaerobic VC degraders


- Previous work at 5 different cVOC sites with different concentrations and biodegradation rates but generally low in DO and ORP
 - Found high concentrations of aerobic VC genes/transcripts (EtnC/EtnE) + anaerobic VC genes/transcripts (vcrA/bvcA)
 - Not true with methanotrophs


Parris Island, SC

Parameter	Avg. sample (39) concentrations
PCE + TCE	292 µg/L
cDCE	2651 µg/L
VC	1938 µg/L
Ethene	218 µg/L
Methane	2621 µg/L
DO	0.74 mg/L
ORP	15 mV



Geochemical data





Introduction to MBTs - Key Points

- A variety of MBTs are available to assist in the following:
 - Determine if the remediation is working
 - Selection of the appropriate remediation strategy
 - Transition from active treatment to MNA
 - Additional lines of evidence for the above
- However, the application of which MBT to use must be carefully be considered taking into account the objectives
 - What are your goals?
 - What type of data will you need?
 - Which phase is the site?
 - What is the geochemical data saying (spatially and versus time)?
 - What are your other lines of evidence telling you?



Acknowledgements

- Tim Mattes
- Kerry Sublette
- Dora Taggart
- Mike Hyman
- Bob Borden
- Frank Löffler
- Aaron Peacock
- Brady Lee
- Kate Kucharzyk

Navy Points of Contact



- **Anthony Danko, Ph.D.**
anthony.danko@navy.mil

- **Arun Gavaskar, P.E.**
arun.gavaskar@navy.mil

Questions



Wrap Up



- **Please complete the feedback questionnaire at the end of this webinar. We are counting on your feedback to make this webinar series relevant!**

- **Next OER2 Webinar Info....**

Title: Rehabilitation and Maintenance of Pump and Treat Systems

Presenter: Jennifer Segura (NAVFAC) and Fred Payne (ARCADIS)

Date: 31 January 2018


Time: 1100-1200 PDT

- **Thank you for participating!**

Backup Material



- **Is biodegradation occurring?**
- ^{13}C label compound added to the 'environment'
- Knowledge of microbes or pathways involved is not required
- Only the active cells will incorporate the ^{13}C



- Cannot be used for electron acceptors

- **Isotope ratio shifts for COCs**
 - Larger for chemical or biological processes
 - Smaller for physical processes
 - Differentiates between them (destructive and non-destructive)
- **Can be used with both electron donors and acceptors**
 - MTBE, cVOCs, etc.
 - 2-D (C-H, C-Cl, etc) or even 3-D may be appropriate (C-H-Cl)
 - Can be used to discriminate between abiotic/biotic and also different degradation pathways (aerobic versus anaerobic)
- **Forensics**
 - Perchlorate - 2-D plot of $^{37}\text{Cl}/^{18}\text{O}$ clustering from natural versus artificial
- **Applications to Vapor Intrusion**